

# Bushnell®

**GOLF**



TOUR **V5**



TOUR **V5** **SHIFT**


## **LASER RANGEFINDER**

### **Quick Start Guide**

Model # 201900/201910

02-20

Model# 201910  
(SHIFT)



**Bushnell**<sup>®</sup>  
**GOLF**  
TOUR **V5**  
TOUR **V5** **SHIFT**

### Basic Operation/Controls


1. Remove protective disc from battery compartment (1)
2. Press Fire/Power button (2) to activate display and fire laser
3. Rotate eyepiece Fast Focus (3) for sharp display
4. To select distance units (yards<>meters), press Fire/Power (2), then hold Y/M button (4) until units change in display.
5. Slope Switch (5) enables/disables slope compensated ranging (Shift model # 201910 only)



Model# 201900

English

## Display Guide



# Bushnell®

## GOLF

Customer Service: (800) 423-3537  
[www.bushnellgolf.com](http://www.bushnellgolf.com)

©2019 Bushnell Outdoor Products